

型号/规格	产品描述	产品外观特征及照片	生产批号/批次
WSG-HSL270G	FIT SAXA 飞特飒 飒剪·儿童型·安全 型·绿色·150mm (刀刃52mm) · 左手用	 	50321
			50419
			50421
			60227
			61022
			70423
			70509
			71021
			71022
			71223
			71230
			80609
			81113
			81212
			90329
			90706
			90918
			00418
			00606
			00926
			01010
			01128
			10327
			10605
			10724
			10819
			20425
			20912

WSG-HS270B	FIT SAXA 飞特飒 飒剪·儿童型·安全 型·蓝色·150mm (刀刃52mm) · 右手用		50321
			50419
			50421
			51205
			60326
			60625
			61022
			61116
			70320
			70423
			70617
			70816
			70916
			70920
			71021
			71101
			71118
			71223
			80314
			80512
			80520
			80704
			81008
			81125
			81212
			90123
			90413
			90417
			90424
			90511
			90518
			90629
			91019
			91211
			00215
			00311
			00408
			00523
			00606
			00822
			01031
			01128
			10102
			10321
			10406
			10501
			10516
			10522
			10626
			10717
			10731
			10807
			10814
			10819
			10918
			11017
			11023
			11030
			11106
			20226
			20425
			20611
			20618
			20702
			20716
			20806

WSG-HS270P	FIT SAXA 飞特飒 飒剪·儿童型·安全 型·粉红·150mm (刀刃52mm) · 右手用	 	50321
			50419
			50421
			60227
			60326
			61022
			61116
			61221
			70423
			70807
			70916
			70920
			71101
			71118
			71223
			80512
			80520
			80609
			81008
			81204
			81212
			90123
			90329
			90413
			90525
			90622
			90629
			91019
			91026
			00219
			00408
			00418
			00523
			00606
			00822
			00926
			10102
			10321
			10406
			10501
			10522
			10703
			10717
			10724
			10731
			10814
			10819
			10830
			10918
			11113
			11120
			20226
			20302
			20528
			20604
			20618
			20625
			20723
			20806
			20912

WSG-HS235B	FIT SAXA 飞特飒 飒剪·儿童型·标准 型·蓝色·131mm (刀刃50mm)	 	50913 60423 70114 70708 71216 80520 81204 90213 90511 90622 90912 91109 00219 00425 00523 00831 00912 10102 10303 10424 10501 11017 11113 11218 20425 20625
WSG-HS235P	FIT SAXA 飞特飒 飒剪·儿童型·标准 型·粉红·131mm (刀刃50mm)	 	50913 60423 70415 71021 80314 81031 90213 90615 90810 91109 00219 00418 00606 01128 10303 10626 10731 11113 11127 11218 20430 20625